

STANLEY®

Instructions for how to install filter bag to your STANLEY vacuum

1. Unlatch the powerhead, and detached the powerhead from the tank.
2. Remove the filter bag from the packaging, unfold the filter bag.
3. Connect the port on the filter bag to the deflector inside the tank, make sure the filter bag is gently push all the way in.
4. Put the powerhead onto the tank, close the latches. The vacuum is ready for use.

*This filter bag is intended for dry pick up only.

If you have questions or comments, please contact us.

Call us at 1-888-899-0146

Or

Visit us www.altonindustries.com