

EVERBILT™



ADJUSTABLE FLOOR GUIDE

Guía de piso ajustable

Adjustable for any door width.

INSTRUCTIONS:

1. Apply adhesive strip on the inside of door guides.
2. Mark center of overlap and place center of Floor Guide in line.
3. Mark screw holes and drill $7/64$ in pilot holes.
4. Fasten and tighten the door guide with screws.
5. Slide the door all the way to ensure proper installation.



Ajustable para cualquier ancho de puerta.

INSTRUCCIONES:

1. Aplica una tira adhesiva en la parte interior de las guías de piso.
2. Marca en centro de la superposición y coloca en línea el centro de la guía de piso.
3. Marca orificios para tornillos y taladra orificios piloto de $7/64$ pulg (2.8 mm).
4. Sujeta y aprieta la guía de piso con tornillos.
5. Desliza la puerta por completo para asegurar la correcta instalación.



**Recycle
Recicla**

MADE IN / HECHO EN CHINA
DISTRIBUTED BY / DISTRIBUIDO POR
HOME DEPOT
2455 PACES FERRY RD., N.W.
ATLANTA, GA 30339
HOMEDEPOT.COM

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects defects or other reproductive harm.

ADVERTENCIA: Este producto contiene químicos que el estado de California reconoce como causantes de cáncer, malformaciones congénitas y otros daños al sistema reproductor.